



**SLIDE BRACKETS TOGETHER,
BOLT SUPPORT BRACKET TO PANEL.**

**LEVEL FILTER BOX AND ADJUST BRACKET TO
CORRECT SIZE.**

**USE TEK SCREWS TO SECURE BRACKETS
TOGETHER.**

COLMET	
Spray Booths	
FINAL FILTER BOX LEG INSTALLATION	
PROJECT NO.	INSTALLATION DETAIL SHEET 15
DATE	
SCALE	
BY	
CHECKED	
APPROVED	