



**NOTE: BEFORE INSTALLING THE DOOR YOU MUST HAVE BOTH DOOR CHANNELS AND TOP DOOR STOP INSTALLED AND SQUARED. CONFIRM THE WIDTH BETWEEN CHANNELS AND FLOOR TO DOOR STOP IS THE SAME AS THE DOOR DRAWING.**

**1. INSTALLING LEFT DOOR**

- A. PLACE SPACERS BETWEEN DOOR AND FLOOR. DOOR IS MANUFACTURED TO HAVE 1" CLEARANCE AT BOTTOM, 1/2" CLEARANCE ON TOP AND 3/8" CLEARANCE ON SIDES.
- B. PUT HINGES IN PLACE PER DRAWINGS. INSTALL SCREW IN CENTER OF SLOTS A AND C ON ALL HINGES. DO NOT TIGHTEN SCREWS AT THIS TIME.
- C. ADJUST THE DOOR IN ALL DIRECTIONS. ASSURE THE DOOR CLOSES COMPLETELY, THEN TIGHTEN SCREWS.
- D. INSTALL SCREWS IN CENTER OF SLOTS B AND D.
- E. REMOVE SPACERS.

**2. INSTALLING RIGHT DOOR**

- A. PLACE SPACERS BETWEEN DOOR AND FLOOR. DOOR IS MANUFACTURED TO HAVE 1" CLEARANCE AT BOTTOM, 1/2" CLEARANCE ON TOP AND 3/8" CLEARANCE ON SIDES.
- B. PUT HINGES IN PLACE PER DRAWINGS. INSTALL SCREW IN CENTER OF SLOTS A AND C ON ALL HINGES. DO NOT TIGHTEN SCREWS AT THIS TIME.
- C. ADJUST THE DOOR IN ALL DIRECTIONS. ASSURE THE DOOR CLOSES COMPLETELY, THEN TIGHTEN SCREWS.
- D. INSTALL SCREWS IN CENTER OF SLOTS B AND D.
- E. REMOVE SPACERS.



All drawings, sketches and/or specifications accompanying or attached to these quotes are the property of Col-Met Spray Booths. If the said quote(s) of Col-Met Spray Booths are not accepted the said drawings, etc. shall be returned to Col-Met Spray Booths. All digital data is issued for information only. You should use this data for reference purposes only to assist in coordinating your work and is supplementary to formally issued paper drawings. In all instances the contract issue drawings govern. It is the responsibility of the recipient to check all digital information against the contract documentation. Col-Met Spray Booths accepts no liability or responsibility for any loss or damage suffered as a result of (or in connection with) the use or misuse of the CAD data supplied for information only. Once the data is introduced into your own CAD or other system, Col-Met Spray Booths can take no responsibility for its accuracy.

FILE LOCATION: T:\Design Manual\Standard Parts\Hinge Installation.dwg		DRAWING VIEW: DOOR HINGE INSTALLTION	
JOB NO.: -	DRAWN BY:	DISTRIBUTOR:	
DATE:	DATE: 11/14/2006	PLOTTER:	
PLOTTED BY: Paul Welch	LAST SAVED DATE: 11/13/2006	PWP USER:	
CHECK DATE:	CUSTOMER P.O.:	FILE NAME:	REV.:
APPROVAL:	-	HINGE INSTALLATION.DWG	
ORDER DATE:	SCALE: -	SIZE: 11x17	SHEET: -